

HCC 03: Soakage

1. INTRODUCTION

This practice note¹ has been developed to provide general information for on-site stormwater soakage. Design information is provided for the standard soakage device designed to have capacity for the 10 year ARI event and also for a soakage reduced at-source measure, sized for a smaller event, refer Sections 2 and 3 below.

1.1 What is soakage?

Soakage is the process of helping stormwater absorb into the ground using specially designed soakage devices. Soakage allows for the infiltration of stormwater into the soil which recharges the groundwater table whilst filtering out contaminants.

1.2 Description

Soak pits/trenches and surface soakage features are the two main soakage systems. Soak pits/trenches provide volume for storage below ground level for stormwater to infiltrate into the surrounding ground.




Figure 1: Typical Chamber Soak-pit
(Source: NZBC E1/VM1 Figure 13)




Figure 2: Typical Rock Soak-pit
(Source: NZBC E1/VM1 Figure 13)

Surface soakage devices include swales, tree pits² or permeable paving³. The advantage of surface soakage devices is that they include pre-treatment before the stormwater infiltrates the ground. Their ability to provide water storage is dependent on their designed dimensions. Surface soakage devices can also be a landscape feature that enhances the visual amenity of a site and the surrounding area.

1.3 Advantages of on-site soakage

On-site stormwater soakage provides the following benefits:

- *Improved water quality by filtering out contaminants.*
- *Improved hydrological response of stormwater peak flow by holding and releasing stormwater in a controlled and more natural manner.*
- *Supports groundwater recharge.*
- *The design of surface soakage devices can add to the amenity of the site and surrounding area.*

1.4 Definitions

ARI: Annual Recurrence Interval. The average or expected value of the periods between exceedances of a given rainfall total accumulated over a given duration.

Building Code: Acceptable solutions and verification methods set out under the Building Code. For more information, contact Council's Building Control Unit on (07) 838 6699.

Infiltrate: Water being absorbed / soaking into the soil.

Impermeable Surfaces: Impervious surfaces that is not vegetated and does not infiltrate run-off, such as roads, roof tops, footpaths, paving, covered or close-boarded decking, swimming pools, patios or highly compacted soil such as clay.

Percolation Rate: The rate at which water is able to soak into the soil.

Pre-treatment: Cleaning of stormwater prior to entry into the soak pit.

Porous: A surface that water is able to pass through.

Soakage device: A mechanism designed to encourage water to infiltrate into the soil.

Stormwater: Rainwater collected on impervious surfaces e.g. roofs, roads, driveways, paths and hard ground areas (also called runoff).

¹ The Three Waters Management Practice Notes are a Hamilton City Council controlled document and will be subject to an ongoing review process. The latest version of the Practice Notes can be downloaded from the Hamilton City Council Website <http://www.hamilton.govt.nz/our-council/council-publications/manuals/Pages/Three-Waters-Management-Practice-Notes.aspx>

² Refer Practice Note HCC04 Bioretention

³ Refer Practice Note HCC07B Permeable paving

2. SOAKAGE – 10 YEAR ARI

2.1 Minimum design requirements

The following information is intended as a guide only. All soakage systems within Hamilton City require specific design by a suitably qualified person and approval from Hamilton City Council's Building Control Unit.

Soakage systems must meet the following minimum design requirements (consistent with the approach in the HCC Infrastructure Technical Specification (ITS):

- Capacity is adequate for a 10 Year ARI event, for the maximum potential impermeable area draining to it and located in such a way to maximise the collection of site runoff.
- Soakage devices must not be located within a 10 Year ARI flood plain, and if possible should be located outside the 50 Year ARI flood plain. They shall be located away from overland flow paths.
- Rate of soakage determined through a soakage test with an appropriate reduction factor (at least 0.25) applied to accommodate loss of performance over time.
- Secondary flow paths shall be provided for water to follow during events that exceed the design capacity of the soakage device.
- Confirmation that the soakage system will not have an adverse effect on surrounding land and properties from land stability, seepage, or overland flow issues.
- Pre-treatment device to minimise silt ingress.
- Interception of hydrocarbons from nearby contaminated sites.
- Access for maintenance.
- A discharge permit may be required from the Waikato Regional Council.
- Soakage devices must not be located close to buildings or boundaries. A clearance of 3.0m is generally required, but this can be reduced to 1.0m for porous paving, or can be reduced to 1.5m where the neighbouring property is required to have a 1.5m setback to any new building. Setbacks to roadside boundaries shall be 0.5m (to avoid fence footings). Further encroachment will require a site-specific design (including PS1 certification) to be carried out.
- Soakage devices should not be located beside retaining walls. For walls less than 2.0m high, the clearance must not be less than a horizontal distance that is equal to the retaining wall height plus 1.5m, unless a site-specific design (including PS1 certification) is carried out. The site-specific design must take into account geotechnical considerations, and ensure stormwater from the soakage device will not enter the cut-off drain for the retaining wall. For walls higher than 2.0m, a site specific design must always be carried out.
- Soakage devices must not be located within 2.0m of public sanitary sewers or 1.0m of private sewers.

- Soakage devices must not be positioned on unstable slopes.
- Soakage devices are to be positioned above the 'winter' high water table unless specifically approved to operate as predominately summer soakage systems. The peak soil wetness period for Hamilton is usually July-September. In the absence of specific field data, the position of the high water table can be estimated when boreholes or test pits are constructed from observations of soil colouration and wetness. If no high water table can be discerned in the field then a suggested adjusting factor for investigations done at other times is shown in Table 1 below:

Table 1: Groundwater seasonal adjustments

TIME OF TESTING	ADJUSTMENT TO SITE OBSERVATION - ASSUME GROUNDWATER RAISES
Dec-March	1.0m higher than found during inspection
April-May, November	0.65m higher than found during inspection
June, October	0.35m higher than found during inspection

- Soakage devices shall not be shared between properties.

2.2 Design procedure

Local consulting engineers and contractors should be able to provide advice and guidance on soakage appropriate to your property based on their technical knowledge of soakage devices they have previously specified for Hamilton City properties. An Integrated Catchment Management Plan (ICMP) may have been prepared for the area, if so that ICMP may provide some soakage information.

Consulting engineers are also able to provide site-specific design services for difficult locations and soil situations. If in doubt as to what is appropriate for your property, consultation with such professionals is advised. The Yellow Pages contain a comprehensive list of consulting engineers. For soakage design, talk to engineers with geotechnical capabilities and experience.

The following methodology will generally be adopted to design a soakage device:

Step 1: Determine soil conditions

Depending on the location of your property, the soil condition can vary. The principal characteristics of the soil profile determine overall soil drainage capability. The following table is a brief guide to soil soakage suitability.

Table 2: Soil soakage suitability

SOIL TYPE* LEGEND ON MAP	SOIL TYPE/DESCRIPTION	OCCURRENCE	COMMENTS	
UNSUITABLE	Kn	Kainui silt loam	Mainly in eastern part of city	
	Hm	Hamilton clay loam	Mainly in southern and western parts of the city	
	O	Ohaupo silt loam	Southern part of the city	
	Rk	Rotokauri clay loam	Small pockets all over the city	
	Rkv	Rotokauri clay loam, Very gently sloping phase	Small area near Dinsdale	
	K	Kaipaki peaty loam and loamy peat	Mainly west of the Waikato River	
	V	Tamahana soils	Hinuera Terrace	
SUBJECT TO SOIL TEST	Kk	Kirikiri complex	Waikato River flood plain	
	Tk	Te Kowhai silt loam and clay loam	Mainly east of the Waikato River	
	Tkp	Te Kowhai peaty clay loam	Near Ruakura	
	R	Rukuhia peat	Outskirts of the city west of Melville	
	H	Horotiu sandy loam	Mainly central city area and Hamilton East	
	Ha	Horotiu mottled sandy loam	Major areas between Kent Street, Frankton Railway and Bankwood	
	Hb	Horotiu sandy clay loam	Refer soil type H	
	Hs	Horotiu sand	Normally adjacent to soil type H	
	Hsg	Horotiu sand with gravels	Normally adjacent to soil type H	
	T	Te Rapa peaty loam	Frankton, Te Rapa and Ruakura	
SUITABLE	Tp	Te Rapa peaty sandy loam	Mainly west of Te Rapa	
	Ts	Te Rapa peaty sand	Near Sunshine Ave, west of the main trunk railway	
	Mh	Tamahere gravelly sand (on Horotiu soils)	Adjacent to Waikato river at Te Rapa, Chartwell. Smaller areas at Melville and south of Hillcrest	
	W	Waikato loamy sand, sand, and sandy loam	Adjacent to Waikato River	
	Mw	Tamahere gravelly sand (on Waikato soils)	Mainly near Chartwell and St Andrews	
				Soil of the plain. Refer to your engineer and Building Code for test results.
				Soil of the plain. Generally suitable for soakage. Initial site investigation is recommended.
			Soil of the low river terraces. Generally suitable for soakage. Initial site investigation is recommended.	

This information is based on Soil Survey Report 31 published by New Zealand Soil Bureau in 1979. Please refer to it for the legend of soil types. To view the map, you can visit or contact Council's Building Control Unit phone: (07) 838 6699.

Step 2: Undertake soil tests

Soil tests are required to confirm that the soil on your property is capable of achieving the minimum percolation rate. The test should be conducted by a suitably qualified Engineer.

A step-by-step guide to do this test is available on the Department of Building and Housing website: www.building.dhb.govt.nz in the Building Code, Clause E1 Surface Water.

The ability of the ground to accept stormwater can vary enormously within soakage areas, even within individual properties. Because of this, at least one percolation test will normally be required for every soakage device that is constructed and this should be done where the soakage device is likely to be placed.

Exceptions to the above expectations for testing are:

- Extensions to car parking or paving of less than 50m² may use a rock filled trench along the lower edge of dimensions 0.5m wide and 0.5m deep.
- Soakage device for an impervious area less than 40m² can use nominal soak holes for Hamilton as described in Council's guidance 'Soak up your Stormwater' which is available from Hamilton City Council⁴.

⁴ <http://www.hamilton.govt.nz/our-services/building-consents-and-information/buildhamilton/Documents/Soak%20up%20your%20Stormwater.pdf>

- **Note: larger areas may not use multiples of these nominal designs - specific engineering design will be required.**

Generally within Hamilton, soakage (with storage) will be expected to be utilised where soakage results are >150mm/hr as determined using the Building code E1 Method.

Soakage is allowed in soils with lower soakage however specific engineering design is required and for soils with low permeability rates.

Step 3: Size the soakage system

The Building Code advises that soakage should be designed to accommodate a 60-minute storm of the size that might be expected once every 10 years. In Hamilton, this equates to a depth of 44.7mm over an hour (climate change adjusted).

Refer to the Worksheet 5, Section 4, Appendix A of the ITS for design templates and a step by step process for designing soakage systems, which is available from the Hamilton City Council website.

Depending on site conditions you may need to consider additional requirements such as peat recharge and high ground water levels.

Recharging of peat: Stormwater management on peat soils is important. It is important to achieve the correct balance of soil recharge to mimic the pre-development soil moisture content. Council defines peat soil as those with more than 300mm of peat between 0.5m and 4.0m of the natural ground surface. Refer to Council’s ITS for further details on how to manage peat soils.

3. SOAKAGE – REDUCED AT-SOURCE MEASURE

If there is a council approved downstream stormwater management device providing stormwater flow attenuation and stormwater quality treatment for your site, you can provide soakage on lot designed as a reduced at-source measure only, referred to as soakage reduced (refer to HCC01 Overview for further discussion about this topic).

3.1 Minimum design requirements

A soakage reduced device should be designed in accordance with the minimum design requirements and design procedure described above for the standard 10 year ARI soakage device (consistent with approach in the ITS), except the capacity of the device is sized differently, as outlined below:

- Capacity is adequate to cater for 5mm runoff from the maximum potential impermeable area draining to the soakage device and is located in such a way to maximise the collection of site runoff. Refer to Figure 3 below for an indicative schematic of the typical arrangement for a soakage reduced device. The device is to be conservatively designed allowing for no infiltration and must take into account void space within the media where applicable.
- Refer to Section 2.1 Minimum design requirements for all other details.
- It is important to ensure the soakage device is above the winter high water table, as per o) in Section 2.1 above.




Figure 3: Schematic showing typical arrangement for soakage reduced

3.2 Example

The following example clarifies how to design a soakage reduced device for a 500m² lot with:

- 250m² house and garage, and
- 125m² driveway and hardstand area
- The soakage reduced device is to be a gravel filled soakage trench with a void ratio of 0.38.

The soakage reduced device is sized for 5mm runoff from contributing impervious areas within the lot.

$$\text{Required soakage volume} = (250\text{m}^2 + 125\text{m}^2) \times 5\text{mm} / 0.38 = 4.9\text{m}^3$$

The remaining design parameters for the soakage reduced device are determined in accordance with Section 2.1 of this practice note - Minimum design requirements.

3.3 Indicative soakage reduced device sizings

The following table provides indicative sizing for a gravel filled soakage trench (void ratio of 0.38) for a range of connected impervious areas:

Connected impervious area (m ²)	Soakage reduced volume (m ³)
50	1 (min)
100	1.3
150	2.0
200	2.6
250	3.3

300	3.9
350	4.6
400	5.3

4. SUMMARY OF PLANNING REQUIREMENTS

Your soakage system must be consented either as part of the whole site’s building consent or as a separate building consent.

For details on building consents please contact Hamilton City Council’s Building Control Unit phone (07) 838 6699.

Soakage systems serving >40m² should be sized for the 10 year ARI event and are required to be designed by a suitably qualified person based on the guidance provided in this practice note and council’s Infrastructure Technical Specification and other best practice guidance. As-laid plans, authorised by a registered drain layer, are required for your soakage system and shall be provided to council.

If your soakage system is designed to be a reduced at-source measure, as long as you comply with the minimum design requirements outlined in this practice note and council’s Infrastructure Technical Specification, specific engineering design is not required for your soakage system (make sure you check the soakage device is above the winter high water table). As-laid plans are still required for your soakage device, authorised by a registered drain layer, and shall be provided to Council.